

MP3 Speaker

USER GUIDE

© Jazwares, Inc. 2012

CONTENTS

Please read the instructions along with the Speaker carefully before you use it, so that you can operate it conveniently.

WELCOME, Warnings & Safety	3
Playing Music	4
Knowing Your Audio Speaker	5
Warranty	6-7
Notes	8
Features & Specifications	9

Package Contents

1. Universal Audio Speaker
2. Built-in 3.5mm Plug Cable
3. USB Cable
4. Owner's Manual with Warranty

Congratulations on your purchase of the Speaker! We hope you enjoy all the great features. To get the most out of your speaker please read this manual as it provides tips and information about its various features.

Safety Precautions

To extend the life of your device, all the following operating and safety instructions should be read, adhered to and followed before the unit is operated.
For your Safety:
1. Please carefully read this user manual before operating the unit.
2. Take a few moments to review the user manual while using your unit for the first time.
3. Do not place or store the unit in areas where it can be exposed water or other liquids. Care should
be taken so that water or other liquids cannot be spilled onto the unit.
4. Protect the unit from vibration, or shock. Always keep it on a flat dry surface.
5. Unplug the unit when it is not in use for extended periods.

Warning:
Replacement of batteries must be done by an adult.
Do not mix old and new batteries.
Do not mix the alkaline, standard (carbon-zinc) and
rechargeable (nickel-cadmium) batteries.
The supply terminals are not to be short-circuited.
Non-rechargeable batteries are not to be recharged.
Exhausted batteries are to be removed.
Only batteries of the equivalent type are to be used.
Batteries are to be inserted with the correct polarity.
Dispose of batteries properly.
Do not dispose of batteries in fire ; batteries may explode or leak.

Maintenance

1. Please clean the unit with a soft dry cloth.
2. Do not press the unit with undue pressure or place any other objects on it.

Playing Music

You can connect your Universal Audio Speaker to your MP3, tablets, e-readers or most mobile phones that has a 3.5mm headphone jack in order to listen to music.
To do so, follow the steps below:

1. In order to power your Universal Audio Speaker, plug one end of the USB cord into a USB adpater(not included), then plug into a standard wall outlet in your home. Connect the other end into the “DC 6V” port on the rear of your Universal Audio Speaker. OR Disconnect the USB cord and insert 4 AA batteries in the base of Universal Audio Speaker.

2. Plug 3.5mm headphone jack into your MP3, e-readers or most mobile phones.

3. Press the power button on your Universal Audio Speaker to turn it on. Red LED indicates power On.



Knowing Your Audio Speaker:


Premium sound stereo speakers
Stand for most mobile phones, music players, and tablets
Power Switch
USB (cord included) or DC input (cord not included)
Power indicator light
Cord can be stored in base
4 AA Battery compartment in base. (batteries not included)
Universal 3.5 mm Jack

Limited Ninety (90) Day Warranty:

WARRANTY COVERAGE

Jazwares, Inc.'s warranty obligation is limited to the terms set forth below.

WHO IS COVERED

Jazwares, Inc. warrants the product to the original purchaser or the person receiving the product as a gift against defects in material & workmanship as based on the date of the original purchase from an authorized dealer or retailer. The original sales receipt showing the product name & the purchase date from an authorized retailer is considered such proof.

WHAT IS COVERED

Jazwares, Inc. warranty covers new products if a mechanical defect arises & a valid claim is received within the Ninety (90) Day Warranty Period. At its option, Jazwares, Inc. will either (1) repair the product at no charge,using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new, or serviceable used parts & is at least functionally equivalent or most comparable to the original product in Jazwares, Inc.'s inventory, or (3) refund the original purchase price of the product.

Jazwares, Inc. warrants replacement products or parts provided under this warranty against defects in materials & workmanship from the date of the replacement or repair for ninety (90) days or for the remaining portion of the original product's warranty, whichever provides longer coverage for you. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Jazwares, Inc. property. If a refund is granted, your product becomes Jazwares, Inc. property.

Replacement product can only be sent if all warranty requirements are met. Failure to follow all requirements can result in delay.

WHAT IS NOT COVERED - EXCLUSIONS & LIMITATIONS

The limited warranty applies only to the products manufactured by or for Jazwares, Inc. that can be identified by the trademark, trade name, or logo affixed to it. This limited warranty does not apply to any non Jazwares, Inc. hardware product or any software, even if packaged or sold with the product. Non Jazwares, Inc. manufacturers, suppliers, or publishers may provide a separate warranty for their own products packaged with the bundled product. Jazwares, Inc. is not liable for any damage to or loss of any programs, data or other information stored on any media contained within the product, or any non - Jazwares, Inc. product or part not covered by this warranty.

Limited Ninety (90) Day Warranty:

WHAT IS NOT COVERED - EXCLUSIONS & LIMITATIONS

This warranty does not apply
(a) to damage caused by accident, abuse, misuse, misapplication, or non - Jazwares, Inc. product,
(b) to damage caused by service performed by anyone other than Jazwares, Inc.
(c) to a product or a part that has been modified without the written permission of Jazwares, Inc.

LIMITED WARRANTY DOES NOT COVER

- Shipping charges to return defective product to Jazwares, Inc.
- Product repair and/or part replacement because of improper installation, connections to improper voltage supply, abuse, neglect, accident, unauthorized repair or other cause not within the control of Jazwares, Inc.
- Damage or claims for products not being available for use, or for lost data or lost software.
- Damage occurring to product during shipping.
- A product that requires modification or adaptation to enable it to operate in any country other then the country for which it was designed, manufactured approved and/or authorized, or repair of products damaged by these modifications.
- Product lost in shipment and no signature verification receipt can be provided.
- Failure to operate per Owner's Manual.

BEFORE RETURNING ANY PRODUCT, CONTACT JAZWARES, INC. CUSTOMER SERVICE. Customer service is available 9-6 EST at 1-800-370-1877.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY FOR THE CONSUMER. JAZWARES, INC. SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow exclusions or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you

This warranty gives you specific legal rights. You may have other rights which vary from state to state.

This warranty is only valid in the United States of America.

© Jazwares, Inc.

NOTES:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by switching the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experience radio/TV technician for help.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Features & Specifications:

Specifications

- Abs Housing with Metal Grill
- Stereo Speakers 2 x 2W
- USB Power
- Support AAA Battery x 4 (Not Include)
- 3.5mm Plug Cable
- LED Light Show Power On/Off
- On/Off Switch
- Accessory : USB Cable

© Jazwares, Inc. 2012